




5-IN-1
MAKE-A-BOT™

**INSTRUCTION
MANUAL**



INCLUDED IN THE PACKAGE



WARNING:

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE:

Please save this Instruction Manual as it contains important information.

ATTENTION :

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes, cordons et vis d'emballage. Ils ne font pas partie du jouet.

NOTE :

Il est conseillé de sauvegarder ce manuel d'utilisation car il comporte des informations importantes.

FEATURES

Circle Button/
Mission Selection

Arrow Buttons

Obstacle Detector

Sound
Sensor

Parts Connectors

Power Switch and
Steering Lock Switch

Speaker

Cart Connector

Obstacle
Detector





POWER SWITCH

Switch to either  or  to power V-Bot™ ON. Switch it to  to power V-Bot™ OFF.



STEERING LOCK SWITCH

Switch to  to enable or to  to disable V-Bot™ to turn when moving with Rover Wheels. Disable it when playing missions.



ARROW BUTTONS

Command V-Bot™ to move or to change the selection in Mission Selection.



CIRCLE BUTTON / MISSION SELECTION

Press this to start Mission Selection; or press this to confirm.

PARTS CONNECTORS

Connect the parts to the connectors with matching marks.

OBSTACLE DETECTORS

V-Bot™ detects obstacles or movements with these detectors.

SOUND SENSOR

V-Bot™ detects claps to start patrolling or response in the Ice Walker game.

CART CONNECTOR

Connect V-Bot™ to the cart's hook for V-Bot™ to pull it along.

INSTRUCTIONS

BATTERY REMOVAL AND INSTALLATION

1. Make sure the unit is turned Off.
2. Find the battery cover located on the bottom of the unit, use a screwdriver to loosen the screw and then open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.
4. Install 4 new AA (AM-3/LR6) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended.)
5. Replace the battery cover and tighten the screw to secure.

 **WARNING:**

Adult assembly required for battery installation.
Keep batteries out of reach of children.

 **ATTENTION:**

Les piles ou accumulateurs doivent être installés par un adulte.
Tenir les piles ou accumulateurs hors de portée des enfants.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES

- Remove rechargeable batteries (if removable) from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.
5. If the unit is not working properly, install a brand new set of batteries.

ENVIRONMENTAL PHENOMENA

Electrostatic discharge may cause the unit to malfunction. In these cases, recover the unit by sliding the Power Switch to OFF to turn off the unit. Then slide the Power Switch to Low/High Volume to turn the unit back on, or remove the batteries for 10 seconds and reinstall the batteries then power on the units.

IMPORTANT NOTE:

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S., 1-877-352-8697 in Canada, or by going to our website vtechkids.com and filling out our Contact Us form located under the Customer Support link. Creating and developing VTech products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions you might have. A service representative will be happy to help you.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Supplier's Declaration of Conformity 47 CFR § 2.1077 Compliance Information

Trade Name: VTech®
Model: 5737
Product Name: VTech® 5-in-1 Make-a-Bot™
Responsible Party: VTech Electronics North America, L.L.C.
Address: 1156 W. Shure Drive, Suite 200 Arlington Heights, IL 60004
Website: vtechkids.com

**THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES.
OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:
(1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND
(2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED,
INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.
CAN ICES-003 (B)/NMB-003(B)**

FAQ

Q: My V-Bot™ stops working after turning on.

A: Make sure V-Bot™ has fully charged batteries inside. Replace the batteries with brand new batteries when necessary.

Q: Can I play with V-Bot™ outdoors?

A: No. V-Bot™ is designed to be played with indoors only. V-Bot™ works best on a smooth and level floor.

Q: Can I stop in the middle of a mission?

A: Yes. Hold the circle button for 3 seconds to exit a mission.

Q: My V-Bot™ cannot climb forward on the included rope.

A: Doubling the rope may help improve the climbing performance.

Q: Some of V-Bot's parts do not work/connect correctly and make clicking noises.

A: Make sure V-Bot's parts are assembled correctly by matching the symbols beside the connection points of the parts to those on V-Bot's core. See the Mission Guide for details.

Q: V-Bot™ doesn't move in a straight line when equipped with the Rover Wheels.


A: Make sure the Steering Lock on the bottom of V-Bot™ is switched to the Lock position.

Q: The front wheels of the Rover Wheels do not move.

A: It's normal. Two of the wheels are for assisting V-Bot's movement, they are not connected to the motor.

GETTING STARTED

1 INSERT BATTERIES (to be done by an adult)



- Locate the battery compartment at the bottom of V-Bot™.
- Loosen the screw of the battery compartment using a screwdriver.
- Insert four “AA” alkaline batteries as indicated inside the battery compartment.
- Replace the battery compartment cover and tighten the screw.

2 POWER ON



- Locate the Power Switch at the bottom of V-Bot™.
- Turn the switch to either of the other positions to turn On V-Bot™ with Low or High sound volume.


3 LET'S EXPLORE




Explore more ways to learn and play with the included Mission Guide!

HOW TO ASSEMBLE

- To assemble V-Bot™ to different forms, match the symbols on both sides of the joints.
- A triangle on the body to a triangle on a part



- A circle on the body to a circle on a part



HOW TO PLAY

There are different ways to start the adventure with V-Bot™.

FREE PLAY


Autonomous

Turn V-Bot™ On, and then V-Bot™ will move autonomously and explore the environment.

Clap to Command V-Bot™ to Patrol

Turn V-Bot™ On. While V-Bot™ is autonomous, clap to command V-Bot™ to start patrolling. Press any key to stop it.

Code V-Bot™ to Move

Turn V-Bot™ On. While V-Bot™ is autonomous, press the arrow buttons  to input a move sequence. When it's done, wait 3s and V-Bot™ will execute the moves.

MISSIONS

- Turn V-Bot™ On.
- While V -Bot™ is in Free Play mode, press the circle button to enter Mission Selection menu.
- Use arrow buttons to select one of five missions. A name of the mission will be voiced out during each press.
- Press the circle button to confirm playing the mission.
- Listen to the voice instructions or follow the instructions on the included Mission Guide to play.
- To quit in the middle of a mission, press and hold the circle button for 3 seconds.

Remark:

Make sure the Steering Lock Switch is turned to Off



when playing the missions.

MISSION 1: ASTEROID ESCAPE

Rover
Wheels



- Equip V-Bot™ with the Rover Wheels, and then press the circle button to start the game.
- V-Bot™ demonstrates some moves. Observe the moves and remember them.
- Press the arrow buttons to repeat the moves. If the moves are correct, the game continues by adding one move to the sequence. Complete all the rounds to win.

MISSION 2: ICE WALKER

Big Feet



- Equip V-Bot™ with the Big Feet, and then press the circle button to start.
- A melody plays while V-Bot™ is walking.
- When the melody pauses, clap the number of times requested.
- If the number of claps is correct, V-Bot™ continue to walk, otherwise the game is over. Complete all the rounds to win.

MISSION 3: LAVA CROSSING

Climbing
Arms



- Equip V-Bot™ with the Climbing Arms.
- Tie the ends of the included rope to fixed objects and hang V-Bot™ on the rope with the equipped Climbing Arms. Press the circle button to start.
- V-Bot™ continues to climb on the rope. When a warning signal occurs, waive in front of the Obstacle Detectors as soon as possible to change V-Bot™ climbing direction. If V-Bot™ cannot reverse climbing direction in time, the game is over. Complete all the rounds to win.

MISSION 4: BARRIER BREAKAWAY

Bulldozer Hands



- Equip V-Bot™ with the Bulldozer Hands.
- Place some small and light objects on the floor, and aim V-Bot™ at the objects. Press the circle button to start moving.
- If V-Bot™ cannot hit anything for a long distance, the game is over. Hit the objects to win. There are three rounds per play.

MISSION 5: MINECART RETRIEVAL


Minecart



- Equip V-Bot™ with the Rover Wheels.
- Place the cart on the floor, and aim V-Bot™ (the side with the Cart Connector) at the cart's hook.
- Press the circle button to start moving. If V-Bot™ successfully hooked the cart, V-Bot™ will take the cart and return. There are three rounds per play.

TIPS

PLAY AREA



- DO play with V-Bot™ on a flat and spacious floor. Playing on a table is not recommended, as V-Bot™ loves exploring and may go beyond the edges!
- Flat, smooth surfaces are recommended for best performance.
- Playing with V-Bot™ on thick rugs or carpets is not recommended, as V-Bot™ may get stuck.

STEERING LOCK SWITCH



- Switch the Steering Lock Switch to the Unlock position to enable steering variations. **IMPORTANT NOTE:** the Steering Lock Switch should be locked for the missions to work as intended.

CAUTION PLAYING WITH THE CLIMBING ARMS AND ROPE

- The rope should not be fixed too high to avoid V-Bot™ falling and hitting people or smashing on the ground.
- Make sure the ends of the rope are tied to sturdy and firm locations. Check the stability of the tied locations before proceeding.
- Make sure the rope is level and straight for best performance.

**Visit our website for more information
about our products, downloads,
resources and more.**

vtechkids.com
vtechkids.ca

Read our complete warranty policy online at
vtechkids.com/warranty
vtechkids.ca/warranty

